



HANDLE ACCESSORY FITTING INSTRUCTIONS


FX & CT RANGE

Remove the accessory trim screw from the underside of the handle. Lift away the accessory trim.



UMBRELLA HOLDER

The umbrella holder comes pre-assembled to the accessory station. Attach to the handle using the long screw provided.



Secure the umbrella in the holder using the top screw.




Rotate the umbrella holder for the ideal position during use and storage.



DRINKS & SCORECARD HOLDER





Secure the scorecard holder using the short screw provided.



GPS HOLDER

Attach the GPS bracket to the handle tube, securing with the 2x screws and nuts provided.

Ensure to orientate the brackets as shown right.



Slot the cradle onto the arm and secure to the bracket on the tube using the large bolt supplied.



For More Game Changing Technology Visit
PowaKaddy.com